

The background of the entire page is a photograph of a Magnet Roller assembly, a piece of marine equipment used for recovering objects from the seabed. It consists of a long, dark vertical pole with various mechanical components, including a large, curved metal arm at the top. The pole is partially submerged in blue, rippling water.

# *Olympia Triumph*



---

## **Magnet Roller** Assembly Guide

MADE IN  
BRITAIN





## Introduction

Thank you for purchasing an Olympia Triumph Magnet roller (CFP-MR1).

We recommend you read this step-by-step guide before assembling and keep it to hand for future reference.

As a company, we pride ourselves on providing excellent customer service and aftersales support. If you experience an issue with the product at any time, please do not hesitate to get in touch with our team.





## Product warranty

In the event of any defect in materials or workmanship, please return the product to Olympia Triumph within three years of the purchase date for inspection. We will replace or repair as required. This guarantee does not cover normal wear and tear, accidental damage or misuse. For complete warranty information, please contact Olympia Triumph.





## Magnet roller self-assembly



**Step 1:** Unscrew and remove nut and bolt in top collar using T20 x 100.



**Step 2:** Remove black plastic grommet using a flat headed screwdriver for leverage.





**Step 3:** Slide collar of the tube.



**Step 4:** Place the top collar into the magnet roller.



# Magnet roller self-assembly



**Step 5:** Slide magnet roller and collar back onto the tube section.



**Step 6:** Line up the collar with the hole in the tube section.





**Step 7:** Replace and attach the plastic grommet with the nut and bolt (as removed in step 2).



**Step 8:** Tighten both height adjustable screws in the magnet roller collar using T30 x 150. Tighten so that the collar does not swing freely but can move when pressure is applied.



## Magnet roller self-assembly



**Step 9:** Remove backing strip from pre cut Velcro strip.



**Step 10:** Position Velcro strip below top mushroom insert. Apply pressure to guarantee contact all the way round.



## Notes

[illegible]





Manufacturer contact details:  
Olympia Triumph Manufacturing Limited  
15 Westminster Road  
Wareham  
Dorset, BH20 4SP  
United Kingdom



Scan for digital copy

Tel. (+44) 01929 555350  
Fax. (+44) 01929 550894  
sales@olytri.com

**olytri.com**

Company Registration No. 2510133 UK  
Company VAT No. GB699432578  
EORI No. GB699432578000  
MOD Contractors List Registration No. ICA001  
Special Forces Equipment NATO Suppliers List NCAGE No. U3618  
Exostar No. EXO110273526  
DUNS No. 505589077

© Olympia Triumph 2021. Version 2



Follow us on Instagram @olympiatriumph

